



iVIEW-754TPC Battery Removal

Prerequisite Only

Written By: Robert Clark





TOOLS:

- [Spudger](#) (1)
-

Step 1 — Remove Battery



- Use flat side of the spudger to get under battery and use pressure to release from glue. Do this all the way around battery until it comes off.

i At this point do not attempt to fully remove the battery as it is still attached to the logic board.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 07:24:11 AM.